


CROSS-SECTIONAL DRAWING WITH PARTS LIST L3NG 20-70



1 Pump Casing	+ 62 Mechanical Seal	If Valve Installed:
5 Drain Plug	150 Power Rotor (1)	219 Valve Cone
6 Seal Ring	151 Idler Rotor (2)	220 Spring Plate
30 Non-Drive Side Cover	+ 170 Ball Bearing	222 Adjusting Screw
+ 31 Gasket	172 Back Ring	235 Valve Spring
32 Mounting Screw	173 Snap Ring	281 Lock-Nut
45 Drive Side Cover	174 Snap Ring	
61 Pin	180 Key	
+ Recommended spare parts		